


Don Boyd

SHOP MANUAL

HONDA GENERAL PURPOSE ENGINE

G35



6287801
英 M E3007902
PRINTED IN JAPAN



HONDA
G35

FOREWORD

The G35 shop manual employs a new approach to servicing and repair instruction. You will find it much different from other conventional Honda shop manuals, that is, instead of employing step-by-step descriptions of procedures, this make use of the intuitive understanding of illustrations in setting forth procedures. Obvious or commonly known information is excluded as much as possible from the manual and written instructions are made as concise as possible.

With this approach, illustrations and explanations are closely interrelated and reader can grasp meaning rapidly and clearly.

We invite from you any questions or comments concerning this new approach to shop manual preparation.

HONDA MOTOR CO., LTD.
Service Publications Office

ALL INFORMATION, ILLUSTRATIONS AND SPECIFICATIONS CONTAINED IN THIS SHOP MANUAL ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF PUBLICATION. THE RIGHT IS RESERVED TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE.

NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION.



CONTENTS

A. SPECIFICATIONS	3
1. Specifications	5
2. Performance Curves	6
3. Three-Dimensional Drawings	7
B. PERIODIC MAINTENANCE	10
C. TROUBLE DIAGNOSIS CHART	11
D. FIXING METHOD	13
☆ Service Precautions	14
☆ Engine Disassembly Chart	15
1. Fuel Tank / Muffler / Air Cleaner	16
2. Carburetor / Governor	19
3. Recoil Starter / Covers	23
4. Fly Wheel / Ignition Coil / Breaker Points	27
5. Cylinder Head / Valves	30
6. Crankcase / Piston / Connecting Rod	37
7. Crankshaft / Camshaft	42
E. SERVICE INFORMATION AND TORQUE TABLE	47
1. Service Information	49
2. Torque Table	51
F. SPECIAL TOOLS	52



HONDA
G35

A. SPECIFICATIONS

1. SPECIFICATIONS

2. PERFORMANCE CURVES

3. THREE-DIMENSIONAL DRAWINGS




Item	Specifications
Model	HONDA gasoline engine G35
Type	Single cylinder
Cycles, valve arrangement	4-cycle, side valve type
Total displacement	144 cc (8.79 cu.in.)
Bore and stroke	64 x 45 mm (2.52 x 1.77 in.)
Compression ratio	6.4 : 1
Rated continuous horsepower	2.5 HP/3,600 rpm
Rated maximum horsepower	3.5 HP/4,000 rpm
Maximum torque	0.66 kg-m/3,000 rpm (4.77 ft-lbs/3,000 rpm)
Fuel consumption	310 g/HP-hr (0.68 lb/HP-hr)
Combustion chamber type	L-head Ricardo type
Cooling system	Forced air cooling
Ignition system	High voltage ignition
Ignition timing	20° BTDC, Fixed
Spark plug	BR6HS or B6HS (NGK)
Carburetor	Horizontal butterfly valve
Governor	Centrifugal weight
Air cleaner	Semi-dry type
Lubrication system	Splash system
Oil capacity	0.6ℓ (1.27 US. pt., 1.06 Imp. pt.)
Starting system	Recoil starter or rope starting
Stopping system	Ground switch
Fuel	Automobile gasoline
Fuel tank capacity	2.5ℓ (0.66 US. gal., 0.55 Imp. gal.)
Dry weight	14.0 Kg (30.87 lbs.)

* These specifications may be changed without notice.

2. PERFORMANCE CURVES

HONDA
G35









HONDA
G35

3. THREE-DIMENSIONAL DRAWINGS

CRANKSHAFT PTO TYPE (Q TYPE)



Unit: mm





PTO shaft
rpm: 3600 rpm.
Rotating direction: counterclockwise





P type



U type







V type





HONDA G35

CAMSHAFT PTO TYPE (LD TYPE)



PTO shaft
rpm: 1800 rpm
Rotating direction: counterclockwise

B. PERIODIC MAINTENANCE

HONDA
G35




Item	Inspection interval (hours)	Daily Inspection	First 20 hrs.	Every 50 hrs.	Every 100 hrs.	Every 300 hrs. or Once a year
Check and replenish engine oil		○				
Change engine oil			○		○	
Check air cleaner element		○				
Clean air cleaner				○ *		
Clean fuel strainer					○	
Clean and adjust spark plug					○	
Inspect and adjust ignition timing						○
Inspect and adjust tappet clearance						○
Decarbonize combustion chamber and valves						○
Clean inside of fuel tank						○
Replace fuel tube		Check and renew if necessary.				

* Clean every 10 hrs. or daily when operating under dusty conditions such as threshing, cutting, etc.



C. TROUBLE DIAGNOSIS CHART





☆ **Service Precautions**

☆ **Engine Disassembly Chart**

1. Fuel Tank, Muffler and Air Cleaner

2. Carburetor and Governor

3. Recoil Starter and Covers

4. Flywheel and Electrical System

5. Cylinder Head and Valves








6. Crankcase, Piston and Connecting Rod

7. Crankshaft and Camshaft

★ SERVICE PRECAUTIONS


HONDA G35




<p><input type="checkbox"/> Always replace whenever reassembled.</p> 	<p><input type="checkbox"/> Wash clean parts in/with solvent. Lubricate their sliding surfaces whenever assembled.</p> 
<p><input type="checkbox"/> Tighten fasteners, beginning on center or larger dia. bolts to specs, where sequence is not specified, in a X pattern.</p> 	<p><input type="checkbox"/> Grease by coating or filling where specified as such.</p> 
<p><input type="checkbox"/> Use HONDA or HONDA recommended parts and lubricants.</p> 	<p><input type="checkbox"/> After reassembling, check every possible part for proper installation, movement or operation.</p> 
<p><input type="checkbox"/> Use special tool where so specified.</p> 	<p><input type="checkbox"/> Always check mutual safety when working with partner.</p>

SYMBOLS

These symbols are used throughout the manual to show specific kinds of operation, sequence of service procedures, etc.

 : Indicates items to be performed carefully for safety service or to be read for extended information.

 : Indicates warning or important items.

①, ②, ③ ... : Indicates sequence of service operations.


 : Apply oil.

GREASE : Apply grease.

S. TOOL : Use special tool.




ARROW LINE INDICATES SEQUENCE OF DISASSEMBLY.



< HOW TO USE ABOVE SEQUENCE >

You can disassemble the next parts without disassembling parts each which are connected together by narrow line.

For example: When the valves are replaced.






1. FUEL TANK, MUFFLER AIR CLEANER

HONDA
G35



a. DISASSEMBLY / ASSEMBLY






HONDA G35

< FUEL TANK >

NOTE:

Inspect tank frequently for debris, flush with gasoline if necessary.




* Do not forget the clamp for the high tension wire.

< FUEL COCK >




Before disassembling, be sure to drain the tank.



* After assembling fuel cock, check for leak, and retighten if necessary.




(b) **CLEANING**
< MUFFLER >



Lightly tap it around with soft hammer to decarbonize.

< AIR CLEANER >







(a) DISASSEMBLY / ASSEMBLY




Before disassembly, be sure to drain carburetor.





< FLOAT CHAMBER >






HONDA G35

(b) INSPECTION

< FLOAT HEIGHT >


* Float Height Setting:
11.5 mm (0.45 in.)



- (1) Place carburetor on a level work surface as shown.
- (2) Check that float valve is just beginning to contact float arm tab.
- (3) Measure distance between carburetor body and top of float.


(c) ADJUSTMENT

< FLOAT HEIGHT >



* Bend float arm tab to adjust height.

< CARBURETOR ADJUSTMENT >



NOTE:

All adjustments must be made at normal operating temperature.

- (1) Turn in pilot screw all the way until it bottoms.
- (2) Turn out pilot screw 1-3/8 turns.
- (3) Start the engine.
- (4) Turn throttle stop screw either in or out as necessary until engine idles at 1,400 RPM. Adjust pilot screw for maximum RPM and re-adjust throttle stop screw for 1,400 RPM.



<GOVERNOR AND THROTTLE>


GOVERNOR ADJUSTMENT

Open throttle fully.

Loosen Governor Arm Set Bolt and push Governor Arm towards carburetor until it stops.

Turn Governor Arm Pivot clockwise until it stops.

Tighten Governor Arm Set Bolt.



THROTTLE ADJUSTMENT

Loosen lock nut on Governor Link.


Start engine and open throttle fully (up is open).

Turn adjusting nut on Governor Link to obtain an engine speed of 3,600 RPM.

Tighten lock nut, being careful to not disturb adjustment.



(a) DISASSEMBLY / ASSEMBLY




BOLT, HEX. 6x10

* If installed by bolts other than specified, noise may be developed.



< RECOIL STARTER >








< ASSEMBLY OF RECOIL STARTER >




CAUTION:
Protect hand holding spring with a heavy glove.

- (2) Tie a knot in one end of starter rope and thread free end of rope through the hole on top of the pulley until the knot is pulled up against the hole. Wind rope counterclockwise around pulley and temporarily secure free end in notch with tape.




- (1) Engage hook on outer end of spring on one of the four retaining tabs inside case.

Turn case clockwise to wind spring inside retaining tabs.



- (3) Position pulley inside case, taking care to engage hook on inner end of spring with hook near the center of pulley. (Pulley will not seat fully until the spring is properly engaged with pulley).

- (4) Wind spring by turning pulley counterclockwise three turns.




- (5) Feed free end of rope through hole in case and through handle. Tie a knot at the end of the rope and seat knot against end of handle.



(b) INSPECTION

< ENGINE SWITCH >




Switch is NORMAL if pointer of tester SWINGS when it is turned ON.




4. FLYWHEEL, IGNITION COIL, BREAKER POINTS

(a) DISASSEMBLY / ASSEMBLY



< FLYWHEEL >






(c) ADJUSTMENT

< IGNITION TIMING >

Ignition timing : $20^{\circ} \pm 3^{\circ}$ BTDC (Fixed)

* Ensure that points start to open when line on crankcase and line on special tool align.



* Loosen breaker point mounting screw and adjust points by shifting their base plate back and forth with a screwdriver.

Points should just break open when mark on special tool and mark on crankcase (timing index mark) are aligned.

Rotate flywheel until points are fully open. If point gap is less than 0.3 mm (0.0118 in.) or more than 0.4 mm (0.0157 in.), points must be replaced.

Slightly tighten 14 mm nut.

S. TOOL

Ignition timing adjusting tool
No. 07974-8780000

WHEN SPECIAL TOOL IS UNAVAILABLE:

* Make sure that points start to open when "F" mark on flywheel and line on crankcase align.


3. CYLINDER HEAD VALVES

HONDA
G35



(a) DISASSEMBLY / ASSEMBLY

< CYLINDER HEAD/SPARK PLUG/TAPPET COVER >






< VALVES >

NOTE:


During assembly, take care to not mix intake and exhaust valves.






(b) INSPECTION

< VALVE STEM O.D. >




	Standard	Service limit
IN	6.955 mm (0.274 in.)	Replace if under 6.91 mm (0.272 in.)
EX	6.910 mm (0.272 in.)	Replace if under 6.89 mm (0.271 in.)

< VALVE GUIDE I.D. >




	Standard	Service limit
	7.015 mm (0.276 in.)	Replace if above 7.065 mm (0.278 in.)

< VALVE SEAT WIDTH >



	Standard	Service limit
	0.7 mm (0.028 in.)	Replace if above 1.5 mm (0.059 in.)


< VALVE SPRING FREE LENGTH >



	Standard	Service limit
	27.9 mm (1.098 in.)	Replace if under 26.0 mm (1.024 in.)




< TAPPET CLEARANCE >



Standard: 0.05 ~ 0.10 mm
(0.002 ~ 0.004 in.)

- * Adjust if out of standard.
- * Measure at TDC on compression when cold.

< CYLINDER COMPRESSION >




- * To obtain compression reading, pull vigorously on starter cord 4 to 6 times with throttle and choke fully open.
COMPRESSION: 5.3 kg-cm² (75 PSI) ±20%

If compression is low:
Check head gasket, valve seating and rings.

If compression is high:
Check for excessive intake valve clearance or large carbon deposits in combustion chamber.

< SPARK PLUG GAP >




Standard	Service limit
0.7 mm (0.028 in.)	Adjust if above 0.8 mm (0.031 in.)



(c) ADJUSTMENT / REPAIR


< CYLINDER HEAD CLEANING >



* Do not scratch the surface.


Remove carbon deposits.

< SPARK PLUG CLEANING >



Remove carbon deposits with plug cleaner or wire brush.


< TAPPET CLEARANCE ADJUSTMENT >




* Grind stem end until proper tappet clearance is obtained.
Place valve in GUIDE and slide end over oil stone back and forth.




< VALVE SEAT RESEATING >



- (1) Cut off valve seat with 90° cutter.
- (2) Check valve seat by contacting with a coat of red lead.
- (3) Cut off valve seat width and its position with 120° cutter.
- (4) Finish with 90° cutter.
- (5) Check valve seat width by contacting with a coat of red lead applied to surface.
- (6) Recheck tappet clearance after reseating.




90° CUTTER
No. 07980-8050100




120° CUTTER
No. 07980-0980300

< VALVE LAPPING >



- * Place valve grinding compound and oil between valve and seat and rotate hand valve lapper against seat until two surfaces are lapped together. Do not use excessive compound and remove all traces of compound after lapping.



PROPER VALVE SEAT






ABNORMAL VALVE SEAT

- * Recheck tappet clearance after lapping.




< VALVE GUIDE REPLACEMENT >






6. CRANKCASE, PISTON CONNECTING ROD

(a) DISASSEMBLY / ASSEMBLY







< CRANKCASE COVER >



< CONNECTING ROD LOWER HALF >




< PISTON RING >





< PISTON >


* Face this mark toward valve side.



S. TOOL
PISTON RING COMPRESSOR
No. 07755-0010000


(b) INSPECTION

< PISTON O.D. AT SKIRT >




Standard	Service limit
63.96 mm (2.518 in.)	Replace if under 63.7 mm (2.508 in.)

< PISTON O.D. AT SKIRT >



Standard	Service limit
0.03 mm (0.001 in.)	Replace if above 0.1 mm (0.004 in.)








< PISTON RING GAP >

* Make use of piston top to press in piston ring.

Standard	Service limit
0.3 mm (0.012 in.)	Replace if above 0.6 mm (0.024 in.)




< PISTON PIN O.D. >



Standard	Service limit
15.00 mm (0.591 in.)	Replace if under 14.97 mm (0.589 in.)


< CONNECTING ROD SMALL END I.D. >



Standard	Service limit
15.005 mm (0.591 in.)	Replace if above 15.05 mm (0.593 in.)



< CYLINDER I.D. >



Standard	Service limit
64.0 mm (2.520 in.)	Replace if above 64.1 mm (2.524 in.)


8. CAMSHAFT CRANKSHAFT

HONDA
G35




(a) DISASSEMBLY / ASSEMBLY

CRANKSHAFT PTO TYPE




CAMSHAFT PTO TYPE






< CRANKSHAFT PTO TYPE >



< CAMSHAFT PTO TYPE >





* Though "R" type is camshaft PTO type, it is gear driven type and rotating direction is clockwise.




< VALVE TIMING ALIGNMENT >

CRANKSHAFT PTO TYPE



* Align chamfered tooth to arrow.

CAMSHAFT PTO TYPE




* Align punched marks to each other.



HONDA G35


(b) MEASUREMENT

< CAM HEIGHT >




Standard	Service limit
28.1 mm (1.106 in.)	Replace if under 27.6 mm (1.087 in.)

< CONNECTING ROD BIG END AXIAL CLEARANCE >



Standard	Service limit
0.1 mm (0.004 in.)	Replace connecting rod if above 1.0 mm (0.039 in.)

< CRANK PIN O.D. >





Standard	Service limit
25.980 mm (1.023 in.)	Replace if under 25.7 mm (1.012 in.)



(c) REPAIR


< CRANKSHAFT BEARING REPLACE >

DRIVING OUT



S. TOOL
BEARING PULLER
(Tool on the free market)

DRIVING IN





HONDA
G35

E. SERVICE INFORMATION AND TORQUE TABLE

1. SERVICE INFORMATION

2. TORQUE TABLE



Unit: mm


Piston O.D. at skirt	
Standard	63.96 (2.518")
Service Limit	63.7 (2.508")

Cylinder I.D.	
Standard	64.0 (2.5197")
Service Limit	64.1 (2.524")

Clearance between piston and cylinder	
Standard	0.04 (0.002")
Service Limit	0.12 (0.005")

Valve spring free length	
Standard	27.9 (1.098")
Service Limit	26.0 (1.023")

Tappet clearance	
Standard	0.05 - 0.10 (0.002 - 0.004")




Valve seat width	
Standard	0.7 (0.03")
Service Limit	1.5 (0.06")

Valve stem O.D.		
Standard	IN	6.970 (0.2744")
	EX	6.925 (0.2726")
Service Limit	IN	6.91 (0.2720")
	EX	6.89 (0.2713")

Valve guide I.D.	
Standard	7.0 (0.2756")
Service Limit	7.065 (0.2781")

Clearance between stem and valve guide		
Standard	IN	0.03 (0.001")
	EX	0.075 (0.003")
Service Limit	IN	0.10 (0.004")
	EX	0.12 (0.005")

Cam height	
Standard	17.03 (0.670")
Service Limit	16.5 (0.650")



Clearance between bearing and camshaft	
Standard	0.02 (0.001")
Service Limit	0.1 (0.004")




Piston pin O.D.	
Standard	15.0 (0.5906")
Service Limit	14.97 (0.5894")

Connecting rod small end I.D.	
Standard	15.005 (0.5907")
Service Limit	15.05 (0.5925")

Clearance between piston pin and connecting rod	
Standard	0.005 (0.0002")
Service Limit	0.05 (0.0020")

Connecting rod big end axial clearance	
Standard	0.1 (0.004")
Service Limit	1.0 (0.04")

Point gap	
Standard	0.3 - 0.4 (0.012 - 0.016")



Piston ring side clearance	
Standard	0.01 (0.0004")
Service Limit	0.1 (0.0040")

Piston ring gap	
Standard	0.2 (0.008")
Service Limit	0.6 (0.024")

Crankshaft pin O.D.	
Standard	25.980 (1.0228")
Service Limit	25.7 (1.0118")

Connecting rod big end oil clearance	
Standard	0.027 (0.001")
Service Limit	0.1 (0.004")



Carburetor	6 mm nut	80 – 120 Kg-cm (5.79 – 8.68 ft.-lbs.)
Flywheel	14 mm nut	600 – 650 Kg-cm (43.39 – 47.01 ft.-lbs.)
Cylinder Head	8 x 35 mm flange bolt	200 – 280 Kg-cm (14.46 – 20.25 ft.-lbs.)
Connecting Rod	6 x 37 mm bolt	90 – 110 Kg-cm (6.51 – 7.96 ft.-lbs.)



No.	Tool Name	Tool No.
1.	Piston Ring Compressor	07755 - 0010000
2.	Bearing Driver	07945 - 5420500
<u>3.</u>	Valve Guide Driver	07942 - 8230000
<u>4.</u>	Valve Guide Reamer	07984 - 5900000
5.	"F" Mark Guide	07974 - 8780000
<u>6.</u>	Cutter Holder	07981 - 8050000
<u>7.</u>	90° Cutter	07980 - 8050100
<u>8.</u>	120° Cutter	07980 - 0980300
9.	Cutter Case	07797 - 0510100
10.	Flywheel Puller	07935 - 8050001
11.	Tool Case	07797 - 0010400
12.	Special Tool Set (Including all tools from No. 1 to No. 11.)	07900 - 8780000