




PARTS CATALOG


**Model NB411L(CE SPEC.)
NB411L-E(CE SPEC.)**

MACHINE BODY(NB411L)



NB411L NB411L-E PARTS LIST
MACHINE BODY(NB411L-E)

CE SPEC.



NB411L NB411L-E PARTS LIST

CE SPEC.

MACHINE BODY

KEY NO.	PART NO.	Q'TY		DESCRIPTION	REMARKS
		411L	411L-E		
*1	6411010000	1	1	Pipe,shaft compl.(incl.6)	
6	6301501500	1	1	Snpring,outer	
7	6411011002	1	1	Shaft	
10	6411008000	1	1	Damper	
11	6412006001	1	1	Drum,clutch compl.	
14	0600179850	1	1	Ball bearing (#6003DD)	
15	0031435000	1	1	Snpring,inner	
16	0031517000	1	1	Snpring,outer	
18	6219519501	1	1	Label,caution	
19	6259514700	2	2	Label,caution	
21	6411500401	1	1	Case,clutch	
22	6301501600	1	1	Washer	

NB411L NB411L-E PARTS LIST

CE SPEC.

23	6407006001	1	1	Band ass'y	
28	6411502101	1	1	Stopper	
29	6401503002	1	1	Stopper	
30	6411501300	1	1	Wing nut	
31	0230069970	1	1	Spacer	
32	0016706500	1	1	Bolt	
33	0037108000	1	1	Gasket fiber	
34	6202500400	2	2	Bolt	
35	6202500600	1	1	Washer	
36	0119069910	4	4	Socket head bolt (M6x18SW)	
46	0032006000	1	1	Spring washer	
47	6202500600	1	1	Washer	
*48	6413002000	1	1	Case,gear ass'y (incl.51to67)	
51	0600079990	1	1	Ball bearing (#627ZZ)	
52	6413003000	1	1	Shaft,cutter set	
53	0600129970	1	1	Ball bearing (#6201)	
55	0600129980	1	1	Ball bearing (#600122)	

NB411L NB411L-E PARTS LIST

CE SPEC.

56	6413500400	1	1	Oil seal	
57	0031428000	1	1	Snpring,inner	
58	0031432000	1	1	Snpring,inner	
59	0031512000	1	1	Snpring,outer	
60	6413500500	1	1	Spacer	
61	6413500600-1	1	1	Bolt,oil	

MACHINE BODY

KEY NO.	PART NO.	Q'TY		DESCRIPTION	REMARKS
		411L	411L-E		
62	0011306320	1	1	Bolt ass'y(M6x32)	
63	0011306140	1	1	Bolt ass'y(M6x14)	
64	6308503100	1	1	Washer,clamp	
65	6418500101	1	1	Washer,receive	
66	6308503200	1	1	Nut	
67	6308503300	1	1	Nut	
69	6274500500	-	1	Handle 1	
70	6274500100	-	1	Handle 2	
71	6404502400	-	1	Grip	
*72	6414005001	-	1	Holder,handle ass'y(incl.76,77)	

NB411L NB411L-E PARTS LIST

CE SPEC.

*75	6355004000	-	1	Control lever ass'y	
76	0119059840	-	4	Socket head bolt(M5x25SW)	
77	0119059890	-	4	Socket head bolt(M5x25SW)	
80	6418500200-1	1	1	Guard	
85	0119059780	3	3	Socket head bolt(M5x12SW)	
*90	6452002000	1	1	Clutch(incl.91to94)	
91	6452003000	3	3	Shue,clutch comp.	
92	6452500600	3	3	Bolt,clutch	
93	6452500400	3	3	Spring	
94	6452500300	1	1	Holder	
98	0022706000	1	1	Nut	
99	0043406350	1	1	Screw assy	
*110	6358005005	1	1	Protector ass'y(incl.111to114)	
111	6358007003	1	1	Protector ass'y	

NB411L NB411L-E PARTS LIST

CE SPEC.

112	6258048003	1	1	Protector compl.	
113	0043605400	2	2	Screw ass'y(M5x40W,SW)	
114	0021805000	2	2	Nut(M5)	
116	6254503802	-	1	Handle holder 1	
117	6414507201	-	1	Handle holder	
118	0119059840	-	4	Socket head bolt	
119	6404506600	-	2	Bush	
120	6404506200	-	2	Stopper	
121	0032006000	-	2	Spring washer	
122	0119069930	-	2	Socket head bolt	
123	6414507300	-	1	Handle	
124	6414507400	-	1	Handle	

MACHINE BODY

KEY NO.	PART NO.	Q'TY		DESCRIPTION	REMARKS
		411L	411L-E		
125	6274501000	-	1	Grip	
*126	6355003000	-	1	Control lever ass'y	

NB411L NB411L-E PARTS LIST

CE SPEC.

NB411L NB411L-E PARTS LIST


CE SPEC.

CONTROL LEVER ASSY

FUJIROBIN INDUSTRIES LTD.

NB411L NB411L-E PARTS LIST

CE SPEC.



KEY NO.	PART NO.	Q'TY		DESCRIPTION	REMARKS
		411L	411L-E		
*75	6355004000	1	-	Control lever ass'y(incl.2to18)	
*126	6355003000	-	1	Control lever ass'y(incl.2to18)	
2	6215022030	1	1	Lever	
3	6195013010	1	1	Lever	
4	6195006150	1	1	Top	

NB411L NB411L-E PARTS LIST


CE SPEC.

*6	6355004010	1	1	Wire set(incl.7)	
7	6355004020	1	1	Wire compl.	
12	6195006050	1	1	Spring	
14	0119059980	1	1	Socket head bolt	
15	6215022040	1	1	Nut	
18	6195006060	2	2	Tapping screw	

ENGINE BODY

NB411L NB411L-E PARTS LIST

CE SPEC.



NB411L NB411L-E PARTS LIST

CE SPEC.

ENGINE BODY

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
*1	5411005001	1	Crankcase ass'y(incl.2,3,6)	
2	0440159971	2	Oil seal	
3	0600159880	2	Ball bearing	
4	5411500300-4	1	Cylinder	
5	5411500501	1	Gasket,Cylinder	
6	5411501200	1	Gasket,Crankcase	
7	0119069990	4	Socket head bolt(M6x18)	
8	0119059940	4	Socket head bolt(M5x30SW)	
9	5412001000	1	Crankshaft compl.	
10	5412500800	1	Piston	
11	5402500600	2	Ring,Piston	
12	5412500300	1	Pin,Piston	
13	5412501300	1	Needle roller bearing	
14	0565099990	2	Clip	
15	0323039990	1	Woodruff key	
16	5323006000	1	Muffler,exhaust	
17	0119069780	2	Socket,head bolt(M6x6OW)	
18	5413500100	1	Cover,Muffler	

NB411L NB411L-E PARTS LIST

CE SPEC.

19	5323500200	1	Gasket,Muffler	
20	5413501100	1	Insulator ass'y	
21	5413501200	1	Gasket,Insulator	
22	5416501300	1	Gasket,Caburetor	
23	5413502800	1	Gasket,lead valve	
24	0119059630	1	Socket head bolt(M5x20)	
32	0140069910	2	Screw (M6x16SW)	
33	0140059550	1	Screw(M5x14 W SW)	
34	0043705140	1	Screw ass'y	
36	5413007000-1	1	Valve,lead ass'y	
*37	5415001000-1	1	Starter,Rewind(incl.38to47)	
38	5415001010	1	Reel	
39	5415001020	1	Ratchet	
40	5415001030	1	Spiral spring	
41	5415001040	1	Racthet guide	
42	5415001050	1	Friction spring	
43	5415001060	1	Washer	
44	5245001010	1	Bind screw	

NB411L NB411L-E PARTS LIST**CE SPEC.**

45	5415001140	1	Starter rope	
46	5305002110	1	Starter knob	
47	5415001220	1	Thrust washer	
50	5415503000-1	1	Cap,Starter	
51	5415500100	1	Cover,Cylinder	
52	5416501900	1	Damper	

ENGINE BODY

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
53	0021705000	1	Nut	
54	0140059610	1	Screw(M5x14)	
55	0140059560	1	Screw(M5x20 W SW)	
56	0119059810	1	Socket head bolt(M5x50)	
57	0119059790	2	Socket head bolt(M5x22W)	
58	0031005000	1	Washer(M5)	
60	5416500000	1	Tank fuel	
61	5416500200	1	Tube fuel	
62	0561139982	1	Hose clamp	
63	6255016001	1	Cap Fuel Tank ass'y	

NB411L NB411L-E PARTS LIST


CE SPEC.

64	6255021002	1	Strap unit	
65	0641279990	1	Filter fuel	
66	5516500501	1	Gasket	
*67	5416057000	1	Bracket,Fuel Tank Assy(incl.68)	
68	0230059990	2	Spacer	
69	5416501100	1	Damper	
70	0043705140	2	Screw ass'y(M5x14)	
72	5417023010	1	Flywheel	
73	5417023020	1	Coil	
74	5417037001	1	Cap,Plug	
75	0654009931	1	Spring,Plug cap	
76	0650149710	1	Plug,Spark	
77	5417500300	1	Tube	
78	0119059790	2	Socket head Bolt(M5x22W)	
79	0130069970	1	Bolt ass'y (M6x16 SW)(incl.81)	
80	0200069920	1	Washer	
82	6415500000	1	Stand	
83	0119069900	2	Socket head Bolt (M6x14 SW)	

NB411L NB411L-E PARTS LIST**CE SPEC.**

84	6419500600	1	Label,Model	

CARBURETOR & AIR CLEANER



NB411L NB411L-E PARTS LIST

CE SPEC.

CARBURETOR & AIR CLEANER

KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
*1	5416019001	1	Caburetor(Incl.2to24)	
2	5306009530	1	Body float	
3	5306009160	1	Straight pin	
4	5306009150	1	Needle ass'y	
5	5306009230	1	Float arm	
6	5416019010	1	Jet needle	
7	5306018020	1	Main jet	
8	5306009020	1	Float	
9	5306009220	1	Gasket	
10	5416001110	1	Spring	
11	5416001060	1	Adjust screw	
12	5306009510	2	Screw	
13	8046001530	2	Spring washer screw	
14	5416008021	1	Piston valve	
15	5306009240	1	Throttle valve spring	
16	5306009120	1	Spring plate	
17	5416001040	2	Packing	
18	5306009450	1	E-ring	


NB411L NB411L-E PARTS LIST**CE SPEC.**

19	5416001130	1	Filter	
20	5306009210	1	Gasket	
21	5306009310	1	Cable adjuster	
22	5306009460	1	Nut	
23	5416001030	1	Cable guide	
24	5306009250	1	Cap	
25	5306009260	1	Mixing cap	
26	5416001020	1	Cock body	
27	5416001010	1	Cap	
28	5306002240	1	Screw	
29	5306002410	1	O-ring	
30	5413500401-1	1	Case air cleaner	
31	5413500500-2	1	Cover air cleaner	
32	5413500600	1	Element	
33	5413502700	1	Element air cleaner	
34	0230059990	2	Spacer	
35	0021705000	3	Nut	
36	0140059680	1	Screw(M5x25)	
37	0043705140	2	Screw(M5x14)	
38	0043605580	2	Screw ass'y(M5x58 W SW)	

NB411L NB411L-E PARTS LIST

CE SPEC.

STANDARD ACCESSORY



KEY NO.	PART NO.	Q'TY	DESCRIPTION	REMARKS
*1	6417006002	1	Band ass'y	

NB411L NB411L-E PARTS LIST

CE SPEC.

4	6308503700	1	Cutter	
5	6418500701	1	Cover cutter	
6	6419038001	1	Tool	
10	6351500700	1	Clamp wire	