



219800

Illustrated Parts List

Model Series

219800

TYPE NUMBERS
0001 through 4389.

TABLE OF CONTENTS

Air Cleaner	6
Alternator	9
Blower Housing	6
Camshaft	3
Carburetor	5
Controls	8
Crankshaft	3
Cylinder	2
Cylinder Head	4
Electric Starter	9
Engine Sump	2
Exhaust System	7
Flywheel	7
Fuel Supply	8
Gasket Set - Engine	4
Gasket Set - Valve	4
Governor Spring	8
Ignition	9
Intake Manifold	4
Kit - Carburetor Overhaul	5
Lubrication	2, 3
Operator's Manual	2
Piston, Rings, Connecting Rod	3
Rewind Starter	9
Valves	4
Warning Label	2



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

1319 WARNING LABEL



REQUIRED when replacing parts with warning labels affixed.

1319A WARNING LABEL





REQUIRED when replacing parts with warning labels affixed.




1058 OPERATOR'S MANUAL



1036 EMISSIONS LABEL









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

Assemblies include all parts shown in frames.

12/19/2014







NOTE: This Illustration Represents Several Carburetors. Parts Shown May Not Be Included In All Kits.


121 CARBURETOR OVERHAUL KIT			
51	104	137	987
93	105	617	1266
95	106	634	1266A
	127	276	








121A CARBURETOR OVERHAUL KIT			
51	127A	137A	98A
104A	987A		
105A	633	1266	217
51A	617	1266A	














Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

DC ONLY		DUAL CIRCUIT		5/9 AMP		TRI CIRCUIT		10/16 AMP	
474A	1059	474B	1059	474C	1059	474C	1059	474D	1059
									



NOTE: All stators use a No. 1119 mounting screw.

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



219800

[illegible]

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5709-10

Assemblies include all parts shown in frames.

12/19/2014

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	791759	Flywheel Used on Type No(s). 0001. ----- Note ----- 791759 Flywheel (Used After Code Date 12071600). Used on Type No(s). 0026, 0101, 0110, 0114, 0121, 0122, 0124, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0148, 0150, 0153, 0154, 0155, 0160, 0161, 0166, 0170, 0172, 0174, 0177, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 0733, 0939, 1168, 1177, 1210, 1402, 1515, 1539, 1549, 1581, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3138, 3148, 3154, 3210, 3389, 3402, 3695, 3712, 3733, 4124, 4161, 4389. 698281 Flywheel (Used Before Code Date 12071700). Used on Type No(s). 0026, 0101, 0110, 0114, 0121, 0122, 0124, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0148, 0150, 0153, 0154, 0155, 0160, 0161, 0166, 0170, 0172, 0174, 0177, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 0733, 0939, 1168, 1177, 1210, 1402, 1515, 1539, 1549, 1581, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3138, 3148, 3154, 3210, 3389, 3402, 3695, 3712, 3733, 4124, 4161, 4389.		591760 Flywheel (Used After Code Date 12071600). Used on Type No(s). 0156, 0165, 0175, 3190, 4029, 4156. 693556 Flywheel (Used Before Code Date 12071700). Used on Type No(s). 0156, 0165, 0175, 3190, 4029, 4156. 591761 Flywheel (Used After Code Date 12071600). Used on Type No(s). 0002, 0137, 0158, 0163, 0168, 0171, 0173, 0176, 4028. 693557 Flywheel (Used Before Code Date 12071700). Used on Type No(s). 0137, 0158, 0163, 0168, 0171, 0173, 0176, 4028. 591758 Flywheel (Used After Code Date 12071600). Used on Type No(s). 0113, 0123, 0125, 0151, 0152, 0179, 2118, 1376, 3118, 3151, 3152, 3376. 698282 Flywheel (Used Before Code Date 12071700). Used on Type No(s). 0113, 0123, 0125, 0151, 0152, 0179, 1376, 2118, 3118, 3151, 3152, 3376.	23A	591950	Flywheel (Used After Code Date 12071600). Used on Type No(s). 0004, 0117, 0118, 0132, 0133, 0134, 0144, 0164, 0169, 0287, 0597, 2115, 4118, 4132. ----- Note ----- 693555 Flywheel (Used Before Code Date 12071700). Used on Type No(s). 0117, 0118, 0132, 0133, 0134, 0144, 0164, 0169, 0287, 0597, 2115, 4118, 4132. 24 791757 Key-Flywheel (Used After Code Date 12071600). ----- Note ----- 796335 Key-Flywheel (Used Before Code Date 12071700).	

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

219800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	797009	Piston Assembly (Standard) Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0161, 0163, 0169, 0170, 0172, 0173, 0177, 0287, 0311, 0336, 0371, 0388, 0389, 0421, 0733, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3154, 3389, 3402, 3695, 3712, 3733, 4161, 4389. ----- Note ----- 797010 Piston Assembly (.020" Oversize) Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0161, 0163, 0169, 0170, 0172, 0173, 0177, 0287, 0311, 0336, 0371, 0388, 0389, 0421, 0733, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3154, 3389, 3402, 3695, 3712, 3733, 4161, 4389.		792307 Piston Assembly (Standard) Used on Type No(s). 0001, 0002, 0004, 0110, 0117, 0118, 0121, 0122, 0124, 0125, 0132, 0133, 0137, 0138, 0141, 0143, 0144, 0146, 0147, 0148, 0150, 0151, 0152, 0153, 0156, 0158, 0160, 0164, 0165, 0166, 0168, 0171, 0174, 0175, 0176, 0179, 0322, 0597, 0648, 0664, 0939, 1168, 1177, 1210, 1376, 3138, 3148, 3151, 3152, 3190, 3210, 3376, 4028, 4029, 4118, 4124, 4132, 4156. 792728 Piston Assembly (.020" Oversize) Used on Type No(s). 0001, 0110, 0117, 0118, 0121, 0122, 0124, 0125, 0132, 0133, 0137, 0138, 0141, 0142, 0144, 0146, 0147, 0148, 0150, 0151, 0152, 0153, 0156, 0158, 0160, 0164, 0165, 0166, 0168, 0171, 0174, 0175, 0176, 0179, 0322, 0597, 0648, 0664, 0939, 1168, 1177, 1210, 1376, 3138, 3148, 3151, 3152, 3190, 3210, 3376, 4028, 4029, 4118, 4124, 4132, 4156.	26	797011 Ring Set (Standard) Used on Type No(s). 0161, 0163, 0169, 0170, 0172, 0173, 0177, 0287, 0733, 1402, 1515, 1539, 1549, 1581, 2190, 3026, 3118, 3154, 3389, 3402, 3695, 3712, 3733, 4161, 4389. ----- Note ----- 797011 Ring Set (Standard) (Used After Code Date 09041500). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712. 792306 Ring Set (Standard) (Used Before Code Date 09041600 and After Code Date 08090100). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.		

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
		698375 Ring Set (Standard) (Used Before Code Date 08090200). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.			792306 Ring Set (Standard) Used on Type No(s). 0001, 0002, 0004, 0110, 0117, 0118, 0121, 0122, 0124, 0125, 0132, 0133, 0137, 0138, 0141, 0143, 0144, 0146, 0147, 0148, 0150, 0151, 0152, 0153, 0156, 0158, 0160, 0164, 0165, 0166, 0168, 0171, 0174, 0175, 0176, 0179, 0322, 0597, 0648, 0664, 0939, 1168, 1177, 1210, 1376, 3138, 3148, 3151, 3152, 3190, 3210, 3376, 4028, 4029, 4118, 4124, 4132, 4156.			0177, 0287, 0733, 1402, 1515, 1539, 1549, 1581, 2190, 3026, 3118, 3154, 3389, 3402, 3695, 3712, 3733, 4161, 4389.
		797012 Ring Set (.020" Oversize) Used on Type No(s). 0161, 0163, 0169, 0170, 0172, 0173, 0177, 0287, 0733, 1402, 1515, 1539, 1549, 1581, 2190, 3026, 3118, 3154, 3389, 3402, 3695, 3712, 3733, 4161, 4389.			792643 Ring Set (.020" Oversize) Used on Type No(s). 0110, 0117, 0118, 0121, 0122, 0124, 0125, 0132, 0133, 0137, 0138, 0141, 0143, 0144, 0146, 0147, 0148, 0150, 0151, 0152, 0153, 0156, 0158, 0160, 0164, 0165, 0166, 0168, 0171, 0174, 0175, 0176, 0322, 0597, 0648, 0664, 0939, 1168, 1177, 1210, 1376, 3138, 3148, 3151, 3152, 3190, 3210, 3376, 4028, 4029, 4118, 4124, 4132, 4156.			----- Note ----- 797013 Pin-Piston (Used After Code Date 09041500). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.
		797012 Ring Set (.020" Oversize) (Used After Code Date 09041500). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.			697120 Ring Set (.020" Oversize) (Used Before Code Date 09041600). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.			697099 Pin-Piston (Used Before Code Date 09041600). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.
		697120 Ring Set (.020" Oversize) (Used Before Code Date 09041600). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.			697099 Pin-Piston Used on Type No(s). 0001, 0002, 0110, 0117, 0118, 0121, 0122, 0124, 0125, 0132, 0133, 0137, 0138, 0141, 0143, 0144, 0146, 0147, 0148, 0150, 0151, 0152, 0153, 0156, 0158, 0160, 0164, 0165, 0166, 0168, 0171, 0174, 0175, 0176, 0179, 0322, 0597, 0648, 0664, 0939, 1168, 1177, 1210, 1376, 3138, 3148, 3151, 3152, 3190, 3210, 3376, 4028, 4029, 4118, 4124, 4132, 4156.			
		697120 Ring Set (.020" Oversize) (Used Before Code Date 09041600). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.	27	698469	Lock-Piston Pin (Used After Code Date 02100300). ----- Note ----- 698138 Lock-Piston Pin (Used Before Code Date 02100400).			
		697120 Ring Set (.020" Oversize) (Used Before Code Date 09041600). Used on Type No(s). 0026, 0101, 0113, 0114, 0123, 0134, 0136, 0139, 0142, 0153, 0154, 0155, 0311, 0336, 0371, 0388, 0389, 0421, 2115, 2118, 2189, 2301, 2380, 2381, 2695, 2712.	28	797013	Pin-Piston Used on Type No(s). 0161, 0163, 0169, 0170, 0172, 0173,			

219800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
29	791633	Rod-Connecting (Standard)	56	695129	Pulley-Starter (Used Before Code Date 12082700).	78	691693	Screw (Flywheel Guard)
32	791118	Screw (Connecting Rod)	57	695131	Spring-Rewind Starter (Used Before Code Date 12082700).	78A	690364	Screw (Flywheel Guard)
33	792868	Valve-Exhaust	58	695132	Rope-Starter (Used Before Code Date 12082700).	81	691178	Lock-Muffler Screw
34	791935	Valve-Intake	58A	697316	Rope-Starter (Used After Code Date 12082600).	93	690602	Bushing-Throttle Shaft
35	691279	Spring-Valve (Intake)	60	493926	Grip-Starter Rope	94	794176	Kit-Idle Mixture (Walbro)
36	691279	Spring-Valve (Exhaust)	60A	281434s	Grip-Starter Rope	94A	793610	Kit-Idle Mixture (Nikki)
37	697352	Guard-Flywheel	65	690940	Screw (Rewind Starter) (Used After Code Date 12082600).	95	691636	Screw (Throttle Valve) (Walbro)
37A	697626	Guard-Flywheel Used on Type No(s). 0004, 0117, 0118, 0132, 0133, 0134, 0144, 0156, 0164, 0165, 0169, 0287, 0597, 2115, 4118, 4132, 4156.	73		----- Note ----- 690837 Screw (Rewind Starter) (Used After Code Date 07040800 and Before Code Date 12082700). 697725 Screw (Rewind Starter) (Used Before Code Date 07040900). (No Longer Available. See Reference 1005A For Service Flywheel Fan)	95A	690718	Screw (Throttle Valve)(Nikki)
42	499586	Keeper-Valve	74	697897	Screw (Rotating Screen)	98	495800	Kit-Idle Speed (Walbro)
43	691968	Slinger-Governor/Oil				98A	695408	Kit-Idle Speed (Nikki)
45	690564	Tappet-Valve				104	690525	Pin-Float Hinge (Walbro)
46	793880	Camshaft				104A	694918	Pin-Float Hinge (Nikki)
50	592845	Manifold-Intake				105	231855s	Valve-Float Needle (Walbro)
51	692137	Gasket-Intake				105A	696136	Valve-Float Needle (Nikki)
53	591260	Stud (Carburetor) (Used After Code Date 11120100). ----- Note ----- 690227 Stud (Carburetor) (Used Before Code Date 11120200).				106	690577	Seat-Inlet (Walbro)(Gravity Feed) ----- Note ----- 691780 Seat-Inlet (Walbro)(Pump Feed)
54	691148	Screw (Intake Manifold)				108	691227	Valve-Choke (Walbro)
55	695130	Housing-Rewind Starter (Used Before Code Date 12082700).				108A	698773	Valve-Choke (Nikki)

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
117	591936	Jet-Main (Standard)(Carburetor 794456, 794457, 799244, 799245) Used on Type No(s). 0001, 0002, 0004, 0026, 0110, 0125, 0144, 0155, 0156, 0158, 0160, 0161, 0163, 0164, 0165, 0166, 0168, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0176, 0177, 0179, 0287, 0733, 0939, 1376, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3138, 3148, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4028, 4029, 4118, 4124, 4132, 4156, 4161, 4389. ----- Note ----- 591936 Jet-Main (Standard)(Carburetor 794456, 794457, 799244, 799245) (Used After Code Date 08121400). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597. 591936 Jet-Main (Standard)(Carburetor 794456, 794457, 799244, 799245) (Used After Code Date 08110500). Used on Type No(s). 0101, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 1168, 1177, 1210.		794352	Jet-Main (Standard)(Carburetor 793362) (Used Before Code Date 08121500 and After Code Date 07122500). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597. 794352 Jet-Main (Standard)(Carburetor 793362) (Used Before Code Date 08110600 and After Code Date 07122500). Used on Type No(s). 0101, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 1168, 1177, 1210. 699897 Jet-Main (Standard)(Carburetor 698944 and 698945) (Used Before Code Date 07122600). Used on Type No(s). 0111, 0114, 0117, 0122, 0123, 0124, 0132, 0133, 0134, 0137, 0139, 0141, 0142, 0143, 0146, 0147, 0148, 0150, 0151, 0152, 0286, 0311, 0322, 0336, 0371, 0388, 0389, 0421.	118	698788	Jet-Main (High Altitude) (Carburetor 794456, 794457, 799244, 799245) Used on Type No(s). 0001, 0002, 0004, 0026, 0110, 0125, 0144, 0155, 0156, 0158, 0160, 0161, 0163, 0164, 0165, 0166, 0168, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0176, 0177, 0179, 0287, 0733, 0939, 1376, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3138, 3148, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4028, 4029, 4118, 4124, 4132, 4156, 4161, 4389. ----- Note ----- 698788 Jet-Main (High Altitude) (Carburetor 794456, 794457, 799244, 799245) (Used After Code Date 08121400). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597.

219800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	698788	Jet-Main (High Altitude) (Carburetor 794456, 794457, 799244, 799245) (Used After Code Date 08110500). Used on Type No(s). 0101, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 1168, 1177, 1210.			0137, 0139, 0141, 0142, 0143, 0146, 0147, 0148, 0150, 0151, 0152, 0286, 0311, 0322, 0336, 0371, 0388, 0389, 0421.			08110500). Used on Type No(s). 0101, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 1168, 1177, 1210.
	791405	Jet-Main (High Altitude) (Carburetor 793362) (Used Before Code Date 08121500 and After Code Date 07122500). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597.	121	796185	Kit-Carburetor Overhaul (Walbro)			794653 Carburetor (Nikki) (Used Before Code Date 08110600). Used on Type No(s). 0101, 0123, 0133, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 1168, 1177, 1210.
	791405	Jet-Main (High Altitude) (Carburetor 793362) (Used Before Code Date 08110600 and After Code Date 07122500). Used on Type No(s). 0101, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 1168, 1177, 1210.	121A	796184	Kit-Carburetor Overhaul (Nikki)			593432 Carburetor (Used After Code Date 13092300). Used on Type No(s). 0002, 0004, 0171, 0173, 0175, 0176, 0287, 3148, 4028, 4029, 4118, 4124, 4132, 4156, 4161.
	699898	Jet-Main (High Altitude) (Carburetor 698944 and 698945) (Used Before Code Date 07122600). Used on Type No(s). 0111, 0114, 0117, 0122, 0123, 0124, 0132, 0133, 0134,	125A	590399	Carburetor (Nikki) Used on Type No(s). 0001, 0026, 0110, 0125, 0144, 0155, 0156, 0158, 0160, 0161, 0163, 0164, 0165, 0166, 0168, 0169, 0170, 0172, 0174, 0177, 0179, 0733, 0939, 1376, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3138, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4389.			590399 Carburetor (Nikki) (Used After Code Date 08121400). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597.
					----- Note -----			590399 Carburetor (Nikki) (Used Before Code Date 08121500) Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597.
					590399 Carburetor (Nikki) (Used After Code Date	127	694524	Plug-Welch (Walbro)
					08121400). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597.	127A	690727	Plug-Welch (Nikki)
					590399 Carburetor (Nikki) (Used After Code Date	130	790024	Valve-Throttle (Walbro)
					08121400). Used on Type No(s). 0114, 0117, 0118, 0121, 0122, 0124, 0132, 0134, 0137, 0148, 0597.	130A	698774	Valve-Throttle (Nikki)
					590399 Carburetor (Nikki) (Used After Code Date	131	790901	Kit-Throttle Shaft (Walbro)

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
131A	698776	Kit-Throttle Shaft (Nikki)	203	691381	Crank-Bell			260902 Spring-Governor (Natural)
133	494381	Float-Carburetor (Walbro)	205	691693	Screw (Bell Crank)			Used on Type No(s). 0311, 0371, 0421, 0648.
133A	694914	Float-Carburetor (Nikki)	209	792813	Spring-Governor (Brown)			691278 Spring-Governor
135A	698780	Tube-Fuel Transfer (Nikki)(Gravity Feed)			Used on Type No(s). 0001, 0004, 0026, 0117, 0118, 0122, 0124, 0132, 0133, 0137, 0144, 0156, 0160, 0164, 0165, 0177, 0597, 2115, 2712, 3026, 3712, 4029, 4118, 4124, 4132, 4156.			Used on Type No(s). 0169.
		----- Note -----			----- Note -----	216	691840	Link-Choke
		792022 Tube-Fuel Transfer (Nikki)(Pump Feed)			792602 Spring-Governor (Red)	216A	691281	Link-Choke (Bell Crank)
137	281165s	Gasket-Float Bowl (Walbro)			Used on Type No(s). 0002, 0101, 0114, 0123, 0125, 0134, 0139, 0141, 0147, 0152, 0153, 0158, 0161, 0163, 0168, 0171, 0172, 0173, 0175, 0176, 0179, 0322, 0388, 0389, 1168, 1177, 1402, 1515, 1539, 1549, 1581, 2189, 2190, 2301, 2380, 2381, 2695, 3152, 3190, 3389, 3402, 3695, 4028, 4161, 4389.			Used on Type No(s). 0132, 0152, 0158, 0168, 0171, 0175, 3152, 4028, 4132.
137A	698781	Gasket-Float Bowl (Nikki)			796260 Spring-Governor (Green)	217	695409	Spring-Choke Return
141	790902	Kit-Choke Shaft (Walbro)			Used on Type No(s). 0113, 0121, 0136, 0166, 0142, 0143, 0148, 0151, 0154, 0155, 0170, 0664, 0733, 0939, 2118, 3118, 3148, 3151, 3154, 3733.	222	694042	Bracket-Control
141A	698778	Kit-Choke Shaft (Nikki)			796261 Spring-Governor (Yellow)	227	691374	Lever-Governor Control
141B	790903	Kit-Choke Shaft (Pump Feed)(Walbro) (Used Before Code Date 07122600). Used on Type No(s). 0117, 0118, 0134.			Used on Type No(s). 0110, 0138, 0174, 1210, 1376, 3138, 3210, 3376.	232	691842	Spring-Governor Link
142	790025	Nozzle-Carburetor (Standard)(Walbro)			690576 Spring-Governor (Gold)	238	691843	Cap-Valve
143	790028	Nozzle-Carburetor (High Altitude)(Walbro)			Used on Type No(s). 0146, 0150, 0336.	240	394358s	Filter-Fuel (White, 75 Microns)
186A	796532	Hose-Connector						Used on Type No(s). 0001, 0026, 0101, 0110, 0113, 0133, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0155, 0160, 0166, 0170, 0172, 0174, 0177, 0179, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 0733, 0939, 1168, 1177, 1210, 1376, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3138, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4389.
187	791805	Line-Fuel (Formed)(10-1/4 Inches Long)(Cut to Required Length)						
187A	791806	Line-Fuel (Formed)(21 Inches Long)(Cut to Required Length)						
187B	791766	Line-Fuel (15 Inches Long)(Cut To Required Length)						
187C	791745	Line-Fuel (23 Inches Long)(Cut To Required Length)						
187D	791744	Line-Fuel (Formed)(14 Inches Long)(Cut To Required Length)						
188	691693	Screw (Control Bracket)						
190	796174	Screw (Fuel Tank Bracket)						
192	691986	Adjuster-Rocker Arm						
202	691841	Link-Mechanical Governor						

219800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
240A	691035	Filter-Fuel (Clear, 40 Microns) Used on Type No(s). 0002, 0004, 0114, 0117, 0118, 0121, 0122, 0123, 0124, 0125, 0132, 0134, 0137, 0144, 0148, 0156, 0158, 0161, 0163, 0164, 0165, 0168, 0169, 0171, 0173, 0175, 0176, 0287, 0597, 3148, 4028, 4029, 4118, 4124, 4132, 4156, 4161.	304G	591641	Housing-Blower (Black-Compatible With Canister Style Filter) Used on Type No(s). 0001, 0002, 0004, 0110, 0144, 0165, 0166, 0168, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0176, 0177, 0179, 0287, 0939, 1515, 1539, 1549, 1581, 3026, 3118, 3138, 3148, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4028, 4029, 4118, 4124, 4132, 4156, 4161, 4389.	333	799650	Armature-Magneto
						333A	592841	Armature-Magneto Used on Type No(s). 0001, 0110, 0166, 0170, 0172, 0174, 0177, 0179, 0939, 1515, 1539, 1581, 3026, 3118, 3138, 3148, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 4124, 4161.
261	697176	Screw (Control Slide)				334	691061	Screw (Magneto Armature)
265	691024	Clamp-Casing						
267	794904	Screw (Casing Clamp)						
268	691025	Casing-Control Wire (Cut To Required Length)	304H	591906	Housing-Blower			
269	691026	Wire-Control (Cut To Required Length)	305	697102	Screw (Blower Housing)			
270	691027	Nut (Control Wire Casing)	305A	793376	Screw (Non-Grommet Style Blower Housing)			
271	691028	Lever-Control	305B	795891	Screw (Blower Housing To Intake Elbow)			
276	692255	Washer-Sealing	305C	799370	Screw (Grommet Style Blower Housing)			
300A	796000	Muffler	306	592778	Shield-Cylinder			
300B	795997	Muffler Used on Type No(s). 0114, 0117, 0125, 0133, 0134, 0152, 0158, 0161, 0163, 0166, 0168, 0597, 4161.	307	691693	Screw (Cylinder Shield)			
			309	693551	Motor-Starter			
304		Housing-Blower (Compatible With Panel Style Filter. No Longer Available. See Reference 304H For Replacement Kit).	310	690323	Screw (Starter Motor)			
			311	497608	Brush Set			
			324	796308	Screen-Rotating (Used After Code Date 07040800).			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
337	491055s	Plug-Spark (Resistor) ----- Note ----- 691043 Plug-Spark (EMS) Used on Type No(s). 0001, 0002, 0004, 0121, 0123, 0132, 0134, 0138, 0139, 0143, 0146, 0148, 0151, 0152, 0158, 0166, 0168, 0170, 0171, 0174, 0176, 0177, 0179, 0311, 0336, 0371, 0388, 1168, 1210, 1376, 1402, 1515, 1581, 2118, 2190, 2380, 3118, 3138, 3148, 3151, 3152, 3190, 3210, 3376, 3402, 4132. 792015 Plug-Spark (Resistor EMS) Used on Type No(s). 0110, 0150, 0153, 0154, 0164, 0172, 0643, 0664, 0733, 0939, 3154, 3733, 2301.	356C	399222	Wire-Stop	445	797007	Filter-Air Cleaner Cartridge (Panel Style)
			357	691483	Key-Drive Pulley	445B	591583	Filter-Air Cleaner Cartridge (Canister Style)
			358	697151	Gasket Set-Engine	455	695113	Cup-Flywheel (Used Before Code Date 12082700).
			359	691077	Washer (Ground Terminal)	455A	796615	Cup-Flywheel (Used After Code Date 12082600).
			363	19203	Puller-Flywheel	456	695128	Plate-Pawl Friction (Used Before Code Date 12082700).
			373	691612	Nut (Ground Terminal)	459	281505s	Pawl-Ratchet (Used Before Code Date 12082700).
			377	691639	Key-Timing	462	691261	Washer (Starter Cable)
			383	19576s	Wrench-Spark Plug	474A	696578	Alternator (DC Only)
			385	694476	Screw (Fuel Pump)			Used on Type No(s). 0114, 0122, 0124, 0137, 0138, 0148, 0160, 0161, 0163, 0170, 0173, 3138, 3148, 4124, 4161.
			385A	690297	Screw (Fuel Pump)	474B	592831	Alternator (Dual Circuit) Used on Type No(s). 0001, 0026, 0101, 0110, 0121, 0136, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0153, 0154, 0155, 0158, 0168, 0171, 0172, 0174, 0176, 0286, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 0733, 0939, 1168, 1177, 1210, 1402, 1515, 1539, 1549, 1581, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3154, 3190, 3210, 3389, 3402, 3695, 3712, 3733, 4028, 4029, 4389.
			387	697090	Pump-Fuel (Includes Mounting Bracket) (Used Before Code Date 08073000).			
			387A	808656	Pump-Fuel			
			404	691691	Washer (Governor Crank)			
			415	794903	Plug (Sump) Used on Type No(s). 0134.			
			415A	794129	Plug (Cover/Retainer) (Used After Code Date 07040800).			
			431	697122	Elbow-Intake			
			431B	797901	Elbow-Intake Used on Type No(s). 0001, 0002, 0110, 0144, 0165, 0166, 0168, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0176, 0177, 0179, 0287, 0939, 1515, 1539, 1549, 1581, 3118, 3138, 3148, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4028, 4029, 4118, 4124, 4132, 4156, 4161, 4389.			
356	697397	Wire-Stop Used on Type No(s). 0026, 0101, 0113, 0114, 0121, 0122, 0123, 0125, 0134, 0160, 0161, 0163, 0173, 0175, 3026, 4028, 4161.						
356A	398808	Wire-Stop Used on Type No(s). 0001, 0002, 0004, 0117, 0118, 0124, 0132, 0133, 0137, 0144, 0152, 0156, 0158, 0164, 0165, 0168, 0169, 0176, 0287, 2115, 2712, 3152, 4029, 4118, 4124, 4132, 4156.						
356B	697089	Wire-Stop Used on Type No(s). 0113, 0123, 0125, 0151, 0152, 0156, 0165, 0166, 0175, 1376, 2118, 3118, 3151, 3152, 3376, 4029, 4156.						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5709-19 Assemblies include all parts shown in frames. 12/19/2014

219800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
474C	592829	Alternator (5/9 Amp Regulated Or Tri Circuit) Used on Type No(s). 0113, 0123, 0124, 0125, 0151, 0152, 0156, 0165, 0166, 1376, 2118, 3118, 3151, 3152, 3376, 4124, 4156.	525	697184	Tube-Dipstick Used on Type No(s). 0001, 0026, 0101, 0110, 0113, 0133, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0155, 0160, 0166, 0170, 0172, 0174, 0177, 0179, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 0733, 0939, 1168, 1177, 1210, 1376, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3138, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4389.	563A	799359	Screw (Guard-Debris Screen)
474D	696458	Alternator (10-16 Amp. Regulated) Used on Type No(s). 0175, 0179, 4029.				578	692306	Wire Assembly
501A	794360	Regulator (5/9 Amp.)				579	691029	Nut (Starter Cable)
501B	698315	Regulator (9 Amp. Battery-Less) Used on Type No(s). 0156, 4156.				584	794682	Cover-Breather Passage (Use With Liquid Sealant Reference 850).
501D	845907	Regulator (10-16 Amp.)				597	691696	Screw (Pawl Friction Plate) (Used Before Code Date 12082700).
503	691532	Strap-Starter				598	799739	Shim-Crankshaft
505	691251	Nut (Governor Control Lever)				601	791850	Clamp-Hose (Green)
507	691972	Insulator				608	695058	Starter-Rewind (Used Before Code Date 12082700).
510	693699	Drive-Starter				608A	591606	Starter-Rewind (Used After Code Date 12082600).
512	796530	Hose-Oil Drain				613	691416	Screw (Muffler)
513	692024	Clutch-Drive				613A	691678	Screw (Muffler)
520	691084	Terminal-Ground				613B	690297	Screw (Muffler)
521	690581	Shield-Cable				614	691620	Pin-Cotter
523	699908	Dipstick				616	692012	Crank-Governor
524	691032	Seal-Dipstick Tube				617	692138	Seal-O Ring (Intake Manifold)
						621	692310	Switch-Stop
						633	699813	Seal-Choke/Throttle Shaft (Nikki)
								----- Note -----
								690597 Seal-Choke/ Throttle Shaft (Walbro)
			526A	697088	Screw (Regulator)	634	690802	Spring/Seal Assembly (Walbro)
			526B	697348	Screw (Regulator)	634A	698779	Spring/Seal Assembly (Nikki)
			552	697144	Bushing-Governor Crank	635	691909	Boot-Spark Plug
			559	697561	Screw (Remote Choke Stop) (Length .375 Inches)	643	697155	Retainer-Air Filter
			559A	693675	Screw (Remote Choke Stop) (Length .419 Inches)	652	793380	Screw (Bracket-Support)
			562	691119	Bolt (Governor Control Lever)	654	690958	Nut (Carburetor)
						670	796175	Spacer
						676	795036	Deflector-Muffler (Side Out)
						677	690661	Screw (Muffler Deflector)

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
684	697157	Screw (Breather Assembly)	789	698329	Harness-Wiring			790443 Dipstick/Tube Assembly
687	697175	Slide-Control	797	693167	Nut (Brush Retainer)			Used on Type No(s). 0002, 0114, 0117, 0118, 0121, 0122, 0123, 0124, 0125, 0132, 0134, 0137, 0144, 0148, 0156, 0158, 0161, 0163, 0164, 0165, 0168, 0169, 0171, 0173, 0175, 0176, 0287, 0597, 3148, 4028, 4029, 4118, 4124, 4132, 4156, 4161.
688	690395	Cap-Friction	801	691283	Cap-Drive			
689	691855	Spring-Friction (Rewind Starter) (Used Before Code Date 12082700).	802	691286	Cap-End			
689A	690529	Spring-Friction (Control Bracket)	823	698941	Screw (Muffler Adapter)			
691	692407	Seal-Governor Shaft	830	691095	Stud-Rocker Arm			
692	691301	Spring-Detent	832	790244	Guard-Muffler			
697	791680	Screw (Drive Cap)	836	690367	Screw (Muffler Guard)			
705	790561	Nut (Fuel Tank)	842	691031	Seal-O Ring (Dipstick Tube)			
718	690959	Pin-Locating	843	697158	Sleeve-Lever			
729	691335	Clip-Wire (Wire Retainer)	847	790442	Dipstick/Tube Assembly Used on Type No(s). 0001, 0026, 0101, 0110, 0113, 0133, 0136, 0138, 0139, 0141, 0142, 0143, 0146, 0147, 0150, 0151, 0152, 0153, 0154, 0155, 0160, 0166, 0170, 0172, 0174, 0177, 0179, 0311, 0322, 0336, 0371, 0388, 0389, 0421, 0648, 0664, 0733, 0939, 1168, 1177, 1210, 1376, 1402, 1515, 1539, 1549, 1581, 2115, 2118, 2189, 2190, 2301, 2380, 2381, 2695, 2712, 3026, 3118, 3138, 3151, 3152, 3154, 3190, 3210, 3376, 3389, 3402, 3695, 3712, 3733, 4389.	850	100106	Sealant-Liquid (Rocker Cover Gasket and Breather Gasket)
729A	691224	Clip-Wire (Starter Motor)				851	692424	Terminal-Spark Plug
741	697128	Gear-Timing				864	796002	Adapter-Muffler (Length 2.25 Inches)
750	790832	Screw (Oil Pump Cover)				868	690968	Seal-Valve
757	793242	Link-Counterweight				877	393456	Wire/Connector- Alternator (Dual Circuit)
758	697391	Counterweight (Used After Code Date 05100200). ----- Note ----- 795940 Counterweight (Used Before Code Date 05100300). Must Use Kit 795940, Includes Sump And Counterweight. 697391 Counterweight (Used After Code Date 05100200). Used on Type No(s). 0134. 795957 Counterweight (Used Before Code Date 05100300). Must Use Kit 795957, Includes Sump And Counterweight. Used on Type No(s). 0134.				877A	393814	Wire/Connector- Alternator (DC Only)
						877B	393537	Wire/Connector- Alternator (5/9 Amp. Regulated Or Tri Circuit)
						877C	399916	Wire/Connector- Alternator (10-16 Amp. Regulated)
						877D	790544	Harness-Wiring
						878	398661	Harness-Alternator
						878A	691955	Harness-Alternator
						883	692236	Gasket-Exhaust
						914	691108	Screw (Rocker Cover)
						918	791851	Hose-Vacuum (Molded)
						920	691656	Solenoid-Starter
						943	690589	Seal-O Ring (Oil Pump Cover)
						949A	799358	Guard-Debris Screen
						950	691657	Screw-Float Bowl (Bottom Of Bowl)
						951	793386	Rod-Choke (Manual Choke)
759	697392	Pin-Counterweight						
773	796448	Retainer						
783	693713	Gear-Pinion						
788	699347	Bracket-Fuel Pump (Used Before Code Date 08073000). Used on Type No(s). 0132.						

219800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
957	799719	Cap-Fuel Tank (Carbon In Cap) Used on Type No(s). 0175, 0287, 4028, 4029, 4118, 4124, 4156.	1005B		Fan-Flywheel (No Longer Available) (See Reference1005A For Service Flywheel Fan).	1059	698516	Kit-Screw/Washer
957A	795027	Cap-Fuel Tank (Standard)	1017	796981	Screen-Oil Pump Used on Type No(s). 0134.	1070	791680	Screw (Flywheel Fan) (Used Before Code Date 07040900).
958	698183	Valve-Fuel Shut Off (Plastic)	1022	272475S	Gasket-Rocker Cover (Used Before Code Date 07091000). (After Date Code Use Liquid Sealant Reference 850)	1070A	690363	Screw (Flywheel Fan) (Used Before Code Date 08061900 and After Code Date 07040800).
964	799159	Cap-Connector (EVAP)	1023	797421	Cover-Rocker	1090	691293	Retainer-Brush
965	499613	Cover-Oil Pump	1024A	794644	Pump-Oil	1091	691333	Cap-Limiter
967	697292	Filter-Pre Cleaner	1026	794573	Rod-Push (Exhaust)	1095	796189	Gasket Set-Valve
968	697420	Cover-Air Cleaner (Black-Compatible With Panel Style Filter)			----- Note -----	1119	691183	Screw (Alternator)
968B	591646	Cover-Air Cleaner (Black-Compatible With Canister Style Filter)			697394 Rod-Push (Intake)	1127	695407	Screw (Float Bowl)
972	799111	Tank-Fuel (Fluorinated) Used on Type No(s). 0175, 0287, 4028, 4029, 4118, 4124, 4156.	1027	492932s	Filter-Oil (Standard)	1136	690278	Screw (Control Bracket)
		----- Note -----	1029	691751	Arm-Rocker	1139	796449	Washer
		792168 Tank-Fuel (Standard)	1034	690822	Guide-Push Rod	1263	697124	Reed-Breather
975	495933	Bowl-Float (Walbro)	1036		Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)	1264	697104	Screw (Breather Reed)
975A	698783	Bowl-Float (Nikki)	1040	698368	Plate-Trim	1266	691917	Seal-O Ring (Intake Elbow)
987	691326	Seal-Throttle Shaft (Walbro)	1044	698139	Screw (Flywheel)	1266A	697123	Seal-O Ring (Intake Elbow)
987A	698777	Seal-Throttle Shaft (Nikki)	1051	691265	Ring-Retaining	1267	697419	Latch-Blower Housing (Black)
1005	796082	Fan-Flywheel (Used After Code Date 07040800).	1054	280275	Tie-Cable	1270	793243	Plug-AVS Counterweight
1005A	796200	Fan-Flywheel (Used Before Code Date 07040900).	1058		276344WST Manual- Operator's 276344TRI Manual-Operator's 276344ZH Manual-Operator's (Chinese)	1319	794467	Label-Warning
						1448	690260	Washer (Magneto Armature)
						1319A	797669	Label-Warning

Not for
Reproduction

Not for
Reproduction

