


32" RIDING MOWER MODEL 3554-4400

NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS. Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED ITEMS ARE INTERCHANGEABLE WITH OPPOSITE SIDE



-1-

32" RIDING MOWER MODEL 3554-4400

ALWAYS GIVE THE FOLLOWING INFORMATION WHEN ORDERING REPAIR PARTS:

1. The PART NUMBER; 2. The PART NAME; 3. QUANTITY DESIRED; 4. The MODEL NUMBER (As shown on Model Plate)

SEND PART ORDERS AS PER INSTRUCTIONS ON THE FRONT PAGE

YOUR UNIT IS RIGHT HAND (RH) OR LEFT HAND (LH) AS YOU STAND BEHIND IT.

DO NOT USE KEY NUMBERS WHEN ORDERING REPAIR PARTS, ALWAYS USE PART NUMBERS.

All replacement parts will be supplied in current production colors or in a neutral color.


A handling fee is applicable to small parts orders.

Key No.	Part No.	Description
1	54873	Trough, Oil Drain
2	48812	Gas Tank
3	Engine	See Footnote Below
4	48049	Gas Line
5	41008	Clip, Gas Line
6	9413447	Locknut, Hex 5/16-18 Thd.
7	120368	Lockwasher, Split, 5/16 In.
8	9413534	Locknut, Hex, 3/8-16 Thd.
9	43955	Vibration Bracket, L.H.
10	44015	Mount, Upper
11	138542	Washer, Shakeproof
12	43954	Vibration Bracket, R.H.
13	180120	Screw, Hex Hd, 3/8-16 x 3/4 In.
14	40974	Shoulder Bolt, Parking Brake
15	43968	Spring, Parking Brake
16	32327	Wave Washer
17	50980	Arm, Parking Brake
18	50562	Spring, Clutch Pedal
19	120386	Flatwasher, 1/4 In.
20	121222	Pin, Cotter, 3/32 x 3/4 In.
21	55722	Brake Pedal Assembly
22	55025	Retainer, Brake Pad
23	53979	Rubber Pad, Brake Pedal
24	43956	Shaft, Brake-Clutch Pedal
25	54715	Rod, Brake
26	271184	Nut, Hex, Keps, 5/16-18 Thd.
27	54723	Bracket, Brake Rod
28	20507	Shoulder Bolt
29	55511	Ground Wire
30	138485	Washer, Shakeproof
31	68542	Decal, Caution
32	53768	Bracket, Axle
33	120228	Screw, Hex Hd, 5/16-18 x 5/8 In.
34	122017	Screw, hex Hd, 5/16-18 x 1 1/4 In.
35	41890	Shoulder Bolt
36	4107	Washer
37	49276	Spring, Main Drive
38	54618	Foot Pad, Right
39	45602	Washer
40	54886	Retainer, Wire
41	54749	Main Frame

Key No.	Part No.	Description
42	54955	Foot Pad, Left
43	45892	Carriage Bolt, 3/8-16 x 1 1/2 In.
44	53782	Idler Arm
45	274517	Flatwasher, 25/64 In.
46	35374	Pulley, Idler
47	39659	Belt Retainer
48	22053	Retaining Ring
49	3021	Key, Woodruff, No. 606
50	55520	Pulley, Transaxle
51	54758	V-Belt
52	43980	Rod, Clutch
53	123567	Screw, Hex Hd, 7/16-20 x 1 In.
54	120363	Lockwasher, Split, 7/16 In.
55	55795	Pulley, Engine
56	33200	Key, Engine Pulley
57	49896	Belt Guide, Trans. Drive Belt
58	50653	Belt Guide, Blade Drive
59	44016	Mount, Lower
60	42273	Sleeve
61	180112	Screw, Hex Hd, 5/16-18 x 2 3/4 In.
62	137185	Pin, Cotter, 1/4 x 1 In.
63	58258	Shift Bracket
64	54569	Washer, 1/4 In.
65	58255	Screw, Nylock, 1/4-28 x 3/4 In.
66	50818	Washer, 1/2 In.
67	55514	Knob, Gear Shift
68	55526	Shift Lever
69	54713	Bracket, Stabilizer
70	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
71	538498	Screw, Hex Wa. Tap, 5/16-18 x 3/4 In.
72	642	Flatwasher
73	42815	Flatwasher
74	40394	Hub Cap
75	36625	"E" Ring
76	35410	Spring, Brake Return
77	Transaxle	Peerless 4 speed Model 900
78	122077	Screw, Hex Hd, 5/16-18 x 2 1/2 In.
79	39628	Key, 3/16 x 3/16 x 2 1/2 In.
80	42091	Tire
81	24167	Valve Stem
82	36182	Wheel


32" RIDING MOWER MODEL 3554-4400

NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS. Use of service/replacement parts other than original equipment parts may void your warranty.



Key No.	Part No.	Description
1	274672	Screw, Hex Hd, 1/4-20 x 3/4 In.
2	60988	Gas Gauge
3	49050	Screw, Plastite, 1/4-10 x 3/4 In.
4	48879	Hood
5	55932	Foam Pad, Hood, R.H.
6	54885	Pad, Vibration
7	456826	Spring Pin, 1/4 x 2 1/4 In.
8	55633	Steering Wheel
9	54902	Bearing, Steering
10	52643	Dash Assembly
11	50117	Lever, Throttle Control
12	39486	Knob, Throttle Control Lever
13	55930	Foam Pad, Hood, Top
14	35287	Screw, Taptite, No. 8-32 x 3/8 In.
15	39492	g Ring
16	44008	Shaft, Steering
17	44008	Pinion Gear
18	454565	Roll Pin
19	52856	Seat
20	20507	Shoulder Bolt
21	56196	Seat Bracket
22	120638	Lockwasher, Split, 5/16 In.
23	120834	Screw, Hex Hd, 5/16-18 x 1 1/2 In.
24	120228	Screw, hex Hd, 5/16-18 x 3/8 In.
25	56220	Spring, Seat
26	56060	Clip, Seat Spring
27	9413447	Locknut, Hex, 3/16-18 Thd.
28	56204	Speed Nut
29	995346	Screw, Taptite, 1/4-20 x 1/2 In.
30	43970	Fender
31	446363	Flatwasher, 5/16 In.
32	122017	Screw, Hex Hd, 5/16-18 x 1 In.
33	44500	Bracket, Deck Guide
34	43964	Bracket, Deck Guide Support
35	39573	Screw, Hex Hd, Lock, 3/8-24 x 1 In.
36	2488	Spring Washer
37	36625	"E" Ring

Key No.	Part No.	Description
38	49930	Upstop Bolt
39	9413534	Locknut, 3/8-16 Thd.
40	120918	Screw, Hex Hd, 3/8-16 x 1 1/2 In.
41	44010	Sector Gear
42	44011	Shoulder Bolt, Sector Gear
43	56226	Console Assembly
44	9424215	Locknut, Hex, 1/4-20 Thd.
45	120382	Lockwasher, Split, 3/8 In.
46	55513	Drag Link Assembly
47	49040	Bracket, Grille Support, R.H.
48	45608	Edging, Hood
49	53678	Grille
50	49041	Bracket, Grille Support, L.H.
51	55537	Bulkhead, Console
52	50720	Shoulder Bolt Axle Pivot
53	122201	Screw, Hex Hd, 3/8-16 x 2 3/4 In.
54	56261	Bracket, Deck Hanger
55	48447	Arm, Steering
56	122145	Screw, Hex Hd, 3/8-16 x 1 1/4 In.
57	50546	Bearing, Spindle
58	56400	Front Axle Assembly
59	56362	Bracket, Front Axle Support
60	274654	Locknut, Hex, 1/4-20 Thd.
61	55870	Spindle, Right
62	55512	Tie Rod
63	55869	Spindle, Left
64	642	Flatwasher, 3/4 In.
65	41096	Tire
66	39879	Bearing
67	24167	Valve Stem
68	39937	Wheel w/Bearing
69	40394	Hub Cap
70	55931	Foam Pad, Hood, L.H.
71	120377	Nut, hex, 3/8-16 Thd.
72	122040	Screw, Hex Hd, 5/16-18 x 1 1/2 In.
73	56235	Cover, Console, Rear




32" RIDING MOWER MODEL 3554-4400

32" RIDING MOWER MODEL 3554-4400

Key No.	Part No.	Description
1	47816	Pull Pin
2	8260	Hairpin Cotter
3	49059	Bar Hitch
4	49058	Lock Bracket
5	9413447	Locknut, 5/16-18 Thd.
6	8413534	Locknut, 3/8-16 Thd.
7	50813	Pivot Bracket
8	120918	Screw, Hex Hd, 3/8-16 x 1 1/2 In.
9	120228	Screw, Hex Hd, 5/16-18 x 3/4 In.
10	43038	Assembly
11	41482	Clip, Press
12	41204	Switch, Lockout
13	45877	Nut (Lockout Switch Part)
14	45878	Lockwasher (Lockout Switch Part)
15	47517	Bracket, Idler Arm
16	47516	Shoulder Bolt
17	122168	Screw, Hex Hd, 3/8-16 x 1 3/4 In.
18	52694	Pulley, Idler
19	52695	Belt Retainer
20	35410	Spring
21	41801	Rivet, Brake Pad
22	41471	Brake Pad
23	53696	Shoulder Bolt
24	47357	Spring, Clutch Lever
25	46563	Shoulder Bolt
26	120392	Flatwasher, 9/32 In.
27	53055	Idler Arm Assy. (Incl. Nos. 21 & 22)
28	9424215	Locknut, 1/4-20 Thd.
29	48478	Grip, Clutch Lever
30	53693	Lever, Clutch
31	46561	Spring, Clutch Lever
32	53247	Quadrant
33	53697	Push Nut
34	51948	Mower Deck
35	68543	Decal, Height Adjustment
36	47352	Cover, Pulley, R.H.
37	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
38	996416	Flatwasher, 3/4 In.
39	48676	Lift Support, Plate Assembly
40	20884	"E" Ring

Key No.	Part No.	Description
41	55724	Pin, Pivot
42	47350	V-Belt
43	56283	Quill Assy. (Incl. Nos. 44-52)
44	51445	Locknut, Flange
45	56365	Flatwasher
46	56391	Pulley
47	56280	Spacer
48	49562	Bearing
49	50818	Spacer, Tube
50	55547	Quill
51	50616	Dust Shield
52	56623	Saddle and Shaft Assembly
53	47353	Cover, Pulley, L.H.
54	68542	Decal, Caution
55	122017	Screw Hex Hd, 5/16 18 x 1 In.
56	50634	Screw, Tapite, 5/16-18 x 3/4 In.
57	47354	Baffle, L.H.
58	39573	Screw, Hex Hd, 3/4-24 x 1 In.
59	2483	Formed Washer
60	54883	Blade, 18 In.
61	55880	Lift Cable
62	39404	Clevis, Lift Cable
63	120372	Nut, Square, 1/4-20 Thd.
64	56180	Hairpin Cotter
65	39522	Pin, Clevis
66	20250	Hand Grip
67	49131	Lever, Height Adjustment
68	120696	Screw, Hex Hd, 5/16-18 x 2 1/4 In.
69	53246	Spring
70	51985	Support, Pivot Tube
71	54608	Pivot Tube Assembly
72	23763	Wheel Axle
73	52584	Wheel Assy., Deck
74	120123	Pin, Cotter, 1/4 x 1 1/4 In.
75	54528	Chute Extension
76	51921	Skid
77	996425	Flatwasher
78	55686	Screw, Mach., 1/4-20 x 3/4 In.
79	271172	Keps Nut, 1/4-20 Thd.
80	56635	Nut, Hex

32" RIDING MOWER MODEL 3554-4400



WIRING DIAGRAM

This diagram is designed to be used as a wiring diagram.

We recommend that unless you are fully qualified to make repairs on the electrical system on this unit, you take it to a competent repairman for such work or adjustments. If wiring is incorrectly hooked up, engine electrical system can be damaged.

NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS. Use of service/replacement parts other than original equipment parts may void your warranty.

Key No.	Part No.	Description
1	49643	Key, Ignition
2	48140	Locknut (Switch Part)
3	138557	Lockwasher (Switch Part)
4	52593	Switch, Ignition w/Keys
5	49211	Fuse
6	55528	Wire Harness Assembly
7	120375	Nut, Hex, 1/4-20 Thd.
8	120380	Lockwasher, Split
9	120392	Flatwasher
10	56360	Bracket, Battery, Hold-Down
11	271172	Nut, Keps, 1/4-20 Thd.
12	40892	Cap. Battery
13	55511	Ground Wire
14	62936	Battery
15	120854	Screw, Hex Hd, 1/4-20 x 5/8 In.
16	40234	Battery Rod
17	56635	Nut, Hex
18	45877	Nut (Lockout Switch Part)
19	45878	Lockwasher (Lockout Switch Part)
20	41204	Switch, Lockout

Key No.	Part No.	Description
21	43038	Wire Assembly, Deck Switch
22	42071	Wire Assembly, By-Pass
23	9424215	Locknut, hex, 1/4-20 Thd.
24	49734	Bracket, Switch Mounting
25	187745	Screw, Hex Hd, 1/4-20 x 3/4 In.
26	121753	Washer, Shakeproof, 1/4 In.
27	53716	Solenoid
28	138485	Washer, Shakeproof, 5/16 In.
29	120368	Locknut, Hex, 5/16-24 Thd.
30		Engine Part
31	54888	Retainer, Wire
32	41482	Wire Clip, Press
33	62800	Lead Wire, Headlight
34	52573	Socket, Headlight
35	52571	Bezel, headlight
36	52572	Bulb, Headlight
37	52570	Lens, Headlight
38	9423773	Screw, Hex Wa. Hd, No. 10-24 x 3/4 In.
39	271166	Nut, Keps, No. 10-24 Thd.
40	9417373	Washer