


ÉCLATÉ 5

Models 660 – 688

Le levier de vitesse ne reculait pas jusque l'encoche



Panneau du couvercle des vitesses

* Attach the short end of spring to the notch in the rear of Ref. No. 2. Attach the long end to Ref. No. 1.
** Shown in orientation for 38-inch deck. Found on tractor models with 38- or 42-inch deck only.