



WIRING DIAGRAM 1556 - G14 (1453) - H14 (1456) - H16 (1656) SOLID STATE IGNITION


**SERIAL NUMBERS 0100101
TO 0299999**




IGNITION SWITCH
VIEWED FROM REAR



POSITION 1 - OFF




POSITION 2 - RUN &
ACCESSORY




POSITION 3 - START

2

**SERIAL NUMBERS 0300101
TO 0399999**




IGNITION SWITCH
VIEWED FROM REAR



POSITION 1 - OFF



POSITION 2 - RUN &
ACCESSORY




POSITION 3 - START

FIGURE 2-15

ELECTRICAL SYSTEM (Continued)

G-14 (1453) SERIAL NUMBERS 0400101 AND UP



- 1. Connector
- 2. Engine
- 3. Starter
- 4. Headlights
- 5. Battery
- 6. Solenoid

- 7. Ignition Switch
- 8. Circuit Breaker
- 9. Interlock Switch
- 10. Amp Meter
- 11. Interlock Switch (On 0500101 and Up Only)